

Remsafe Multi Bolt Installation Instructions

Installation instructions for timber sash windows

1. Locate the lock position on the bottom sash window frame. The Remsafe Multi Bolt may be installed horizontally or vertically on the top left corner or the top right corner of the bottom sash frame.
2. Hold the lock body in position on the window frame and use a pencil to mark the position of the fixings screws and bolt hole.
3. Using a 3mm drill bit, drill pilot holes for the fixing screws, using care to ensure you avoid the glass panel.
4. With the window in the closed position, use a 10mm drill bit to drill the bolt hole through both the front and rear sash frame, using care not to drill too far through the rear sash frame.
5. Use the screws provided to screw the lock body in place.
6. Insert the bolt to test for smooth operation.
7. Tap in the plastic screw plugs over the screw holes.
8. To create the restricted ventilation position, open the bottom sash to the desired position. It is recommended that the opening distance be no greater than 12.5 cm.
9. With the window open in this position, place the bolt through the bolt hole on the lock body and gently tap the bolt with a rubber mallet so that the position is marked on the rear sash window frame.
10. Close the bottom sash to reveal the bolt mark. Drill a 10mm hole for the bolt, using care to ensure you do not drill too far through the rear sash frame.
11. Check the lock for smooth operation
12. Place the rivet plate in the hole to finish.

DO NOT LEAVE THE KEY UNATTENDED IN LOCK AT ANY TIME